

ACKNOWLEDGMENTS

Permission has been received from the American Society of Mechanical Engineers to use and reproduce portions of standards relating to crane operation and safety. The Committee of Wire Rope Producers of the American Iron and Steel Institute grants permission to reproduce or quote their *Wire Rope Users Manual* and the *Wire Rope Sling User's Manual* when used as an editorial reference. Illustrations of lattice boom dismantling/assembly have been reproduced from the *Mobile Crane Manual* by courtesy of Construction Safety Association of Ontario. The Crosby Group, Inc., has granted permission to use information about wire rope clips and illustrations of swivel hoist rings and rigging techniques from *The Crosby General Catalog*.

This page intentionally left blank.

MAIN TABLE OF CONTENTS

	Effective Date
1.0 INTRODUCTION	06/26/98
2.0 RESPONSIBILITIES	10/16/00
3.0 CRITICAL LIFTS	01/15/93
4.0 PERSONNEL QUALIFICATIONS AND TRAINING REQUIREMENTS	08/28/00
5.0 HOOKS	09/27/99
6.0 FORKLIFT TRUCKS	09/04/00
7.0 SHOP CRANES	09/27/99
8.0 WIRE ROPE	09/27/99
9.0 SLINGS	02/16/01
10.0 RIGGING HARDWARE	06/26/00
11.0 BELOW-THE-HOOK LIFTING DEVICES	06/26/00
12.0 HOISTS, JIB CRANES, AND MONORAIL SYSTEMS	05/29/00
13.0 OVERHEAD AND GANTRY CRANES	02/16/01
14.0 MOBILE CRANES	08/28/00
15.0 PERSONNEL LIFTING	08/31/98
16.0 THIS CHAPTER IS ON HOLD	
17.0 THIS CHAPTER IS ON HOLD	
18.0 HOISTING AND RIGGING IN HOSTILE ENVIRONMENTS	01/15/93
19.0 THIS CHAPTER CANCELED	06/26/98
20.0 THIS CHAPTER IS ON HOLD	
21.0 REFERENCES AND BIBLIOGRAPHY	09/11/00
APPENDIXES:	
A DEFINITIONS AND ACRONYMS	02/16/01

This page intentionally left blank.